




# BACK CARE solutions

1  
2  
3  
4  
5  
6  
7  
8  
9

- Remove all items from the box and ensure everything is included (arms and neck rest will only be included if specifically on your order)
- Slot each castor into the feet of the star base if they are not already connected - ensuring they are fully inserted
- Place the star base on the floor and insert the gas stem with the narrow tip facing upwards
- On the underside of the seat mechanism you will find a circular slot for this gas stem tip to go into. Place the seat mechanism onto the gas stem so it fits into the slot
- Once positioned, kneel on the seat and lift the front of the three levers for the seat height to ensure it is securely fitted
- Position the backrest so that the back bar slots into the chair mechanism. It should fall to its lowest position
- Lift the back rest. You should hear the back rest clicking at the different height settings if it is fitted correctly
- If your chair has arm rests these will already be attached to the seat base
- If your chair has a neck rest, slot this into the recess at the top of the backrest

SUPPORT WHERE YOU NEED IT



**BEST HOME  
WORKING  
OFFICE CHAIR**  
ASSEMBLY INSTRUCTIONS