

STEP 01

Remove all items from the box and ensure everything is included - arm rests and neck rest will only be included if specified on your order

STEP 02

Slot each castor into the feet of the star base if they are not already attached, ensuring they are fully inserted

STEP 03

Place the star base on the floor and insert the gas stem with the narrow end facing upwards

STEP 04

On the underside of the seat mechanism you will find a circular slot for the gas stem tip to position into. Place the seat mechanism onto the gas stem so the tip fits into this slot

STEP 05

Once positioned, press down firmly on the seat and lift the front of the three levers for the seat height to ensure it is securely fitted

STEP 06

Ensure the lever on the back rest is in the raised position, then slot the back rest onto the seat mechanism

STEP 07

Once fitted, push the lever on the back rest into the down position to secure it in place

STEP 08


If your chair has arm rests, slot these into the brackets under the seat and tighten the included thumb screw to secure

STEP 09

If your chair has a neck rest, slot this into the recess at the top of the back rest

RH LOGIC 300 & 400

ASSEMBLY INSTRUCTIONS



BACK CARE
solutions

SUPPORT WHERE YOU NEED IT