



# BACK CARE solutions

SUPPORT WHERE YOU NEED IT

1  
2  
3  
4  
5  
6  
7  
8  
9

Remove all items from the box and ensure everything is included (arms and neck rest will only be included if specifically on your order)

Slot each castor into the feet of the starbase, ensuring they are fully inserted

Place the star base on the floor and insert the gas stem with the narrow tip facing upwards

On the underside of the seat mechanism you will find a circular slot for the gas stem to go into. Place this seat mechanism onto the gas stem so it fits into the slot


Once positioned, kneel on the seat and lift the front of the three levers for the seat height to ensure it is securely fitted

Ensure the lever on the back rest is in the raised position and slot the back rest onto the seat mechanism

Once fitted, push the lever on the back rest into the down position to secure in place

If your chair has arm rests then slot these into the brackets under the seat. Tighten the included screw to fix in place

If your chair has a neck rest, slot this into the recess at the top of the backrest



# RH LOGIC

ASSEMBLY INSTRUCTIONS